

LIGHTING THE FIRE OF A FLAM APPLIANCE AND HEATING*


*Also see the guidelines for using the Flam Multi-Turbo appliances and the instructions for the installation and recommendations.

! ATTENTION: NEVER HEAT THE APPLIANCE UNTIL IT IS RED-HOT


PLEASE PAY ATTENTION TO THE FOLLOWING TIPS BEFORE HEATING

Clean out the appliance before heating and de-ash the grill.
Never burn with a full ashtray.

CLEAN & DE-ASHED




Always use dry fuels
(max. moisture content 20 %.)





Open grills for the air for combustion completely before heating.


OPEN




ALWAYS FULLY OPEN THE CHIMNEY VALVE + THE BRAKE-BLOCKS





THE AIR SUPPLY OPENING HAS TO BE FREE OVER THE ENTIRE LENGTH




THE SPOILER ALWAYS HAS TO BE MOVEBLE




1) Put the MT-grill in the IGNITION PHASE, the extreme left.




2) Place 2 to 3 ignition blocks on the grill, at the back.



3) Place the wood flat on the grill (lead right against the back) and cover the openings of the grill.



4) As soon as the appliance burns well, add large woodblocks or a shovel of charcoal, against the back of the appliance.



! ATTENTION : WITH EVERY ADJUSTMENT PUT THE GRILL FIRST COMPLETELY TO THE RIGHT !

MULTI-TURBO GRILL POSITIONS

- ▶ 0 : GRILL CLOSED
- ▶ 1 : POSITION 1 SMALLEST FIRE
- ▶ 2 : POSITION 2 SMALL FIRE
- ▶ 3 : POSITION 3 MEDIUM FIRE
- ▶ 4 : POSITION 4 LARGE FIRE
- ▶ 5 : POSITION 5 LARGEST FIRE
- ▶ 🔴 🔴 🔴 🔴 🔴 : IGNITION PHASE

